# **User Manual**

# <u>GW-3201M1</u>

# Serial to IP Intelligent Gateway with Modbus conversion



## **Disclaimers and Safety**

The accuracy of the information in the manual has been confirmed by the manufacturer. All specification and information are subject to change without prior notification by the manufacturer. The manufacturer makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Manufacturer reserves the right to improve this manual or device at any time without notice.

Device has been tested and complied with safety regulation and certificated for use. s. The purpose of limits is to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. Before you attempt to unpack or use this product, please read the manual and instruction carefully. It will help to protect you from injury andminimize the possibility of risk of damage to the device.

- Follow the safety precautions and warning to reduce any risk.
- Do not expose the unit to rain or put it near water or any liquid during installation.
- Do notinsert any object into this device through any slot or openings.
- Do not put the device on a stable surface to get rid of the risk from vibration or collision.
- Only use the power supply unit dedicatedly designed for this device.
- Do not block the opening and vents to avoid the heating accumulated.

## Package Content

1x GW-3201M1

## **Introduction**

CTR-3201M1 is Serial to IP intelligent Gateway with Modbus conversion. The major purpose of this device is to convert Modus UTP to Modbus TCP (either way). CTR-3201M1 provides one IP port and two Serial ports for conversion. The two serial ports can be used in the same time. The USB port is left to equip with communication kits, such as BLE dongle.

With the Friendtrol Installation Wizard, all of the settings can be completed step by step within few minutes. In addition, since it is based on Friendtrol Edge Computing Platform, the settings for IP port and serial port can be very flexible. There is also an APP available to monitor the status of the conversion.

## **Features**

- Edge Computing based Intelligent Gateway
- 512MB RAM & 8GB ROM embedded
- Support Friendtrol Installation Wizard via web interface
- Support VPN on IP port
- Support White List on IP port
- Support Modbus RTU/ASCII on serial port
- Support log history
- Support APP status monitoring

## Panel Description

#### **Front Panel**



## **Rear Panel**



## Top Panel



1	Power Input	Connect to power supply		
2	Ethernet	Connect to LAN		
3	USB	Connect to communication kits (optional)		
4	Serial Port 1 (RS-232)	Connect to device withRS-232		
		TX of RS-232 (pin3) RX of RS-232 (pin2)		
5	Serial Port 1 (RS-485)	Connect to device with RS-485		
6	Serial Port 2	Connect to device withRS-485		
7	Green LED	TX of Serial Port 2		
8	Red LED	RX of Serial Port 2		
9	Green LED	TX of Serial Port 1		
10	Red LED	RX of Serial Port 1		
11	Yellow LED	System indication		

## **Specification**

## I/O Interface

Ethernet	1 x RJ-45 Connector
	10/100 Mbps
	ICMP, TCP/IP, DHCP, Static IP
Serial Port 1 (RS-232)	1 x DB-9 male connector
	For RS-232 only
Serial Port 1 (RS-485)	1 x 2pins-phoenix terminal block
	For RS-485 only
Serial Port 2 (RS-485)	1 x 2pins-phoenix terminal block
	For RS-485 only
USB (Reserved)	1 x USB3.0 Type A female connector
	Reserved (optional function)

## Others

Power Supply	9-24V DC
Power Consumption	Up to 10W
Operating Temperature	-20°C to 75°C (4°F to 167°F)
Storage Temperature	-40°C to 85°C (-40°F to 185°F)
Enclosure	Plastic
Fixedness	Mounting ear with screws
Humidity	20 - 80% RH [Not Condensation]
Device Dimension	68x88x27 mm (WxDxH)
Package Dimension	160x130x38 mm (WxDxH)

## **Default System Settings**

Please connect your PC to GW-3201M via LAN port. The default IP address of LAN is 192.168.100.1. The account and password for Friendtrol Installation Wizard is listed as below.

#### Installation Wizard:

admin / admin

Intelligent Gateway
Sign in
admin 🚊
Sign in

## **FriendtrolInstallation Wizard**

FriendtrolInstalltion Wizard is a tool to help user to set up this gateway quickly. User just needs to follow the three steps below, and will complete the configuration in a short time.



#### 1. Network

The first step is to set up Ethernet port for general IP settings, white list and VPN.

#### 1-1. Network Setup

This part is to complete the general IP settings.

Friendtrol	GW-3201M1		ර් Reboot   Ad	imin 👻
😤 Quick Setup				
🖓 Network 🗸	Network Setup			
Setup				
Whitelist	LAN 1			
VPN				
Status	DHCP Client	Enable	*	
🚍 Serial Setup +& Gateway Setup	IP Address	192.168.1.50		
🔅 System 💙	Subnet Mask	255.255.255.0		
	Gateway	192.168.1.50		
			Save	

#### 1-2. White List

Sometimes the user might allow the outside system connecting to GW-3201M1. In order to make sure there is no attack from uncertain IP address, white list is built for this case. Therefore only the IP address in the white list can access GW-3201M1.

🤨 Friendtrol		GW-3201M1			
器 Network	~	Network V	Vhitelist		
Setup					
Whitelist		ACCEPTABL	E IP		
VPN					
Status		IP Tables			
📑 Serial Setup		No.	IP		Actior
😪 Gateway Setup	>	1			
- sjoteni					

#### 1-3. VPN

When the user wants GW-3201M1 can access to internet, VPN would be used for security issue. In Friendtrol Edge Computing system, we provide this function to meet this goal.

🕑 Friendtrol		GW-3201M1	
প Quick Setup		_	
Setup	×	Network VPN-PPT	P
Whitelist		VPN-PPTP	
VPN			
Status		Server Hostname	dip.hicast.work
📑 Serial Setup			
🚓 Gateway Setup		Username	vpritest
🔅 System	>	Password	• • • • • •

#### 1-4. Network Status

User can see the Network status in this section.

9 Friendtrol	GW-3201M1			එ Reboot   Admi
Pa Network 🛩	Network Status			
Setup Whitelist	Network LAN1		Network VPN	
VPN	IP Address	192.168.89.199	IP Address	10.44.6.91
Status	Subnet Mask	255.255.255.0	Subnet Mask	255.255.255.255
Serial Setup	MAC Address	b8:27:eb:49:bb:a6	Peer	10.64.64.65
- Gateway Setup	Gateway	192.168.89.1	Gateway	
	Conscient © 2018 Extendent All rights second			

## 2. Serial Setup

The second step is to set up the general settings for the two Serial ports.

🕹 Friendtrol	GW-3201M1		Ů Reboot   Admin ▼
😤 Quick Setup			
윪 Network 💙	Serial Setup		
📑 Serial Setup			
• Gateway Setup	Port1		
🏟 System 🔹 🔉			
	Baudrate	9600	τ
	Parity	None	¥
	Bytesize	8	Ŧ
	Stopbits	1	٣
	XON / XOFF	ON OFF	
	RTS / CTS	ON OFF	
	Timeout	0.5	second(s)
			Save
Installation Wizard	Copyright © 2019 Friendtrol. All rights reserved.		Ver. 1.0.1

## 3. Gateway Setup

This third step is to complete the conversion between Modbus RTU and Modbus TCP. (Bi-directional)

🤨 Friendtrol	GW-3201M1	
육 Quick Setup 品 Network > 픪 Serial Setup	Gateway Setup	
🚓 Gateway Setup	Port1	
🗘 System 🗲	Conversion Type Data Framer	TCP (master) to RTU (slave)
	Listener Port	0.5

## 4. System

This section is to see the log and the status of the whole System, and even set up the system.

Friendtrol	GW-3201M1		
🛠 Quick Setup			
💑 Network 💙	System Lo	g	
📑 Serial Setup			
🚓 Gateway Setup			
💠 System 🗸 🗸			
Setup	Туре	Message	Time
Log	io	$function\_codefunction\_codefunction\_codefunction\_codefunction\$	2019/0
Status			